

Poor Jet Performance

There are a few reasons you may be getting poor jet performance. Please review all steps below. If, after attempting the trouble-shooting steps, your jets are performing poorly, please complete a [Service Request Form](#). (*attach Service Request Form document*)

1. Are your pumps operating? Please review the [Pumps Not Operating](#) trouble-shooting guide to ensure that your pumps are operating properly. (*attach Pumps Not Operating Properly document*)
2. Check your water level to be sure it is adequate (up to minimum safe water level side).
3. Make sure the jets are open and the air controls are open.
4. Check for dirty filters. Clean if necessary. Please review [Filter Maintenance](#) to ensure they are being properly maintained. (*attach Filter Maintenance document*)

If you feel that the jets are not performing as they should, after attempting all the above steps, please complete a [Service Request Form](#). (*attach Service Request Form document*)